



3. WELD PER HP11-1:
2. ANODIZE PER HP4-2 AFTER WELDING.
1. IDENTIFY PER HP8-5 (IMPRESSION STAMP)
NOTES:

INSTRUCTIONS FOR CLEARPRINT FORMS-14

VELLAW "B" NIE FORM 9487 REV. 1-81

SHOP COPY